



ASSEMBLY

- ① APPLY JM CONCRETE PRIMER AT BASE OF WALL AS SHOWN.
- ② INSTALL JM APPROVED BASE FLASHING ON WALL AS SHOWN.
- ③ FASTEN TOP OF BASE FLASHING 6" O.C.
- ④ INSTALL SPECIFIED COUNTERFLASHING
- ⑤ APPLY BASE COAT OF SEAMFREE LIQUID MEMBRANE.
- ⑥ EMBED SEAMFREE SCRIM INTO WET BASE COAT OF SEAMFREE LIQUID MEMBRANE.
- ⑦ APPLY FINAL COAT OF SEAMFREE LIQUID MEMBRANE.

NOTE:

A. REFER TO PERMAFLASH & SEAMFREE LIQUID MEMBRANE INSTALLATION INSTRUCTIONS FOR GENERAL GUIDELINES REGARDING THESE SYSTEMS, INCLUDING THE AMOUNT OF TIME REQUIRED BETWEEN LIQUID MEMBRANE APPLICATIONS.

SEAMFREE BASE FLASHING DETAIL (ALT) - MASONRY WALL

DRAWING NO.

SF-10B

SCALE

N.T.S

ISSUE DATE

12-14-09

REV. NO.

2

CAD FILE:

SF_10.dwg

Johns Manville is a Manufacturer of commercial roofing products and offers this general conceptual information to you as a courtesy. This complimentary assistance is not to be used or relied upon by anyone as a substitute for professional engineering design and documentation required by building code, contract, or applicable law. By accepting these comments you agree they do not constitute any representations, endorsements of, or an assumption by Johns Manville of any liability for either the adequacy of the design of this building or any other material not supplied by Johns Manville.