



NOTE:

A. REFER TO PERMAFLASH & SEAMFREE LIQUID MEMBRANE INSTALLATION INSTRUCTIONS FOR GENERAL GUIDELINES REGARDING THESE SYSTEMS, INCLUDING THE AMOUNT OF TIME REQUIRED BETWEEN LIQUID MEMBRANE APPLICATIONS.

ASSEMBLY

- ① INSTALL DYNAGRIP BASE SD/SA AS SHOWN.
- ② PRIME BOTH SIDES OF METAL DRIP EDGE WITH PERMAFLASH PRIMER.
- ③ INSTALL METAL DRIP EDGE IN PERMAFLASH AND FASTEN AS SHOWN.
- ④ APPLY BASE COAT OF SEAMFREE LIQUID MEMBRANE OVER DYNAGRIP BASE SD/SA AND EDGE METAL AS SHOWN.
- ⑤ EMBED SEAMFREE SCRIM INTO WET BASE COAT OF SEAMFREE LIQUID MEMBRANE.
- ⑥ APPLY FINAL COAT OF SEAMFREE LIQUID MEMBRANE.

SEAMFREE DRIP EDGE

DRAWING NO.

SF-13

SCALE
N.T.S

ISSUE DATE
12-21-09

REV. NO.
2

CAD FILE:
SF_13.dwg

Johns Manville is a Manufacturer of commercial roofing products and offers this general conceptual information to you as a courtesy. This complimentary assistance is not to be used or relied upon by anyone as a substitute for professional engineering design and documentation required by building code, contract, or applicable law. By accepting these comments you agree they do not constitute any representations, endorsements of, or an assumption by Johns Manville of any liability for either the adequacy of the design of this building or any other material not supplied by Johns Manville.