



STEP A CORNER REINFORCEMENT

STEP B WALL TRANSITION



NOTES:

- A. USE SCRIM DETAIL IN CONJUNCTION WITH THE PERMAFLASH LAYOUT DRAWING, PMF-3.
- B. EMBED ALL PRE-CUT SCRIM INTO A FULL WET BASE COAT OF MBR FLASHING CEMENT. ALLOW EACH COAT TO FULLY CURE BEFORE APPLICATION OF SUBSEQUENT COATS.
- C. ENCAPSULATE ALL SCRIM COMPLETELY WITH A MINIMUM OF A 60 MIL COVERING.
- D. ALL FOLD LINES REPRESENTED AS AND ALL CUT LINES REPRESENTED AS .
- E. JM RECOMMENDS DIMENSION "x" TO BE AT LEAST 6", BUT VARIATION IS ALLOWED FOR LOWER THRESHOLDS.



STEP C WALL REINFORCEMENT

*ADD 3 1/2" IF DETAIL UTILIZES CANT STRIP

PERMAFLASH INSIDE CORNER SCRIM DETAIL

DRAWING NO.

PMF-3S

SCALE
N.T.S

ISSUE DATE
23 FEB 07

REV. NO.
0

CAD FILE:
PMF_3S.dwg

J M
Project Design Mechanical Fastening



Specs

Sheet Layout

Tapered Insulation

Governing Codes

Wind

