



**STEP**  
A **FOLD**



**STEP**  
B **SCUPPER CUTOUT**



**NOTES:**

- A. USE SCRIM DETAIL IN CONJUNCTION WITH THE PERMAFLASH DRAWING LAYOUT, PMF-7.
- B. EMBED ALL PRE-CUT SCRIM INTO A FULL WET BASE COAT OF MBR FLASHING CEMENT. ALLOW EACH COAT TO FULLY CURE BEFORE APPLICATION OF SUBSEQUENT COATS.
- C. ENCAPSULATE ALL SCRIM COMPLETELY WITH A MINIMUM OF A 60 MIL COVERING.
- D. ALL FOLD LINES REPRESENTED AS ----, AND ALL CUT LINES REPRESENTED AS .....
- E. 6" DIMENSION OF SCRIM BASED ON STANDARD 4" FLANGE. FOR ALTERNATE FLANGE SIZES, EXTEND SCRIM 2" BEYOND FLANGE TERMINATION.

**PERMAFLASH THROUGH-WALL SCUPPER SCRIM DETAIL**

DRAWING NO.

**PMF-7S**

SCALE  
N.T.S

ISSUE DATE  
23 FEB 07

REV. NO.  
0

CAD FILE:  
PMF\_7S.dwg

**J M**  
Project Design Mechanical Fastening



**D E S I G N**  
Details Specs Sheet Layout Tapered Insulation Governing Codes Wind

