



**STEP FOLD**  
A



**STEP SCUPPER CUTOUT**  
B



**NOTES:**

- A. USE SCRIM DETAIL IN CONJUNCTION WITH THE PERMAFLASH LAYOUT DRAWING PMF-8.
- B. EMBED ALL PRE-CUT SCRIM INTO A FULL WET BASE COAT OF MBR FLASHING CEMENT. ALLOW EACH COAT TO FULLY CURE BEFORE APPLICATION OF SUBSEQUENT COATS.
- C. ENCAPSULATE ALL SCRIM COMPLETELY WITH A MINIMUM OF A 60 MIL COVERING.
- D. ALL FOLD LINES REPRESENTED AS - - - - - AND ALL CUT LINES REPRESENTED AS . . . . .
- E. 6" DIMENSION OF SCRIM BASED ON STANDARD 4" FLANGE. FOR ALTERNATE FLANGE SIZES, EXTEND SCRIM 2" BEYOND FLANGE TERMINATION.

**PERMAFLASH OVERFLOW SCUPPER SCRIM DETAIL**

DRAWING NO.

**PMF-8S**

SCALE

N.T.S

ISSUE DATE

23 FEB 07

REV. NO.

0

CAD FILE:  
PMF\_8S.dwg

**J M**  
Project Design Mechanical Fastening

**D**  
Details

**E**  
Specs

**S**  
Sheet Layout

**I**  
Tapered Insulation

**G**  
Governing Codes

**N**  
Wind

